

**BIG BIKE PARTS®**

# INSTALLATION INSTRUCTIONS

## FOR CONTOURED CHROME ACCESSORIES

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

**\*\*\*\* NOTE: READ CAREFULLY BEFORE STARTING INSTALLATION \*\*\*\***

**DO NOT REMOVE TAPE BACKING UNTIL PERFECTLY CONTOURED**

1. **CONTOUR** - IT IS IMPERATIVE THE ACCESSORY IS PERFECTLY SHAPED AND POSITIONED BEFORE INSTALLATION. FIT AND SHAPE THE ACCESSORY BY HAND DIRECTLY TO THE BIKE TO INSURE A PERFECT FIT. MAKE GENTLE ADJUSTMENTS WHILE CONTOURING (ABRUPT OR CONTINUOUS BENDING WILL CRACK THE CHROME VOIDING ANY WARRANTY). SOME ACCESSORIES WILL REQUIRE CONSIDERABLE TIME AND NUMEROUS ADJUSTMENTS TO ACHIEVE A PERFECT FIT, BE PATIENT AND TAKE YOUR TIME. IF THE ACCESSORY IS NOT PERFECTLY CONTOURED IT WILL PEEL LOOSE WHERE THE FIT IS INCORRECT.
2. **CLEANLINESS** - THE FINEST MATERIAL WILL NOT ADHERE TO A DIRTY, OILY SURFACE. A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A **CLEAN**, LINT-FREE RAG WILL PREPARE THE SURFACE TO BE COVERED.
3. **APPLICATION** -THERE IS ONLY ONE CHANCE TO INSTALL, OTHERWISE THE ADHESIVE TAPE MAY NOT PROPERLY ADHERE. MAKE A FINAL CONTOUR FIT LOOKING FOR CLOSE FITTING EDGES OR OBSTRUCTIONS. ONLY AFTER YOU HAVE THE PERFECT FIT SHOULD YOU BE READY TO REMOVE THE PROTECTIVE BACKING. LIFT ONE EDGE OF THE PROTECTIVE BACKING ENOUGH SO YOU CAN PEEL IT AWAY IF YOU HOLD THE PART IN POSITION. GENTLY POSITION THE ACCESSORY IN PLACE AND SLOWLY PEEL THE PROTECTIVE BACKING OFF WHILE ADHERING THE ACCESSORY IN PLACE. APPLY SLOW, EVEN PRESSURE WITH A CLEAN DRY RAG AND PUSH FIRMLY IN PLACE, RUBBING FROM THE CENTER OUT TOWARD THE EDGES.
4. **MAINTENANCE** - THE ADHESIVE SHOULD BE ALLOWED TO SET FOR **72** HOURS BEFORE EXPOSURE TO RAIN OR WASHING. AFTER THE ADHESIVE SETS YOU CAN APPLY CHROME POLISH OR WAX TO THE ACCESSORY. PROPER PROTECTION FROM DAILY MOISTURE, SUCH AS DEW OR RAIN, WILL INCREASE THE LIFE OF ALL CHROME ACCESSORIES.

FAILURE TO INSTALL AN ACCESSORY AS PER THE ABOVE INSTRUCTIONS MAY VOID ANY IMPLIED OR WRITTEN WARRANTIES.

**BIG BIKE PARTS®**

# INSTALLATION INSTRUCTIONS

## FOR CONTOURED CHROME ACCESSORIES

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

**\*\*\*\* NOTE: READ CAREFULLY BEFORE STARTING INSTALLATION \*\*\*\***

**DO NOT REMOVE TAPE BACKING UNTIL PERFECTLY CONTOURED**

1. **CONTOUR** - IT IS IMPERATIVE THE ACCESSORY IS PERFECTLY SHAPED AND POSITIONED BEFORE INSTALLATION. FIT AND SHAPE THE ACCESSORY BY HAND DIRECTLY TO THE BIKE TO INSURE A PERFECT FIT. MAKE GENTLE ADJUSTMENTS WHILE CONTOURING (ABRUPT OR CONTINUOUS BENDING WILL CRACK THE CHROME VOIDING ANY WARRANTY). SOME ACCESSORIES WILL REQUIRE CONSIDERABLE TIME AND NUMEROUS ADJUSTMENTS TO ACHIEVE A PERFECT FIT, BE PATIENT AND TAKE YOUR TIME. IF THE ACCESSORY IS NOT PERFECTLY CONTOURED IT WILL PEEL LOOSE WHERE THE FIT IS INCORRECT.
2. **CLEANLINESS** - THE FINEST MATERIAL WILL NOT ADHERE TO A DIRTY, OILY SURFACE. A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A **CLEAN**, LINT-FREE RAG WILL PREPARE THE SURFACE TO BE COVERED.
3. **APPLICATION** -THERE IS ONLY ONE CHANCE TO INSTALL, OTHERWISE THE ADHESIVE TAPE MAY NOT PROPERLY ADHERE. MAKE A FINAL CONTOUR FIT LOOKING FOR CLOSE FITTING EDGES OR OBSTRUCTIONS. ONLY AFTER YOU HAVE THE PERFECT FIT SHOULD YOU BE READY TO REMOVE THE PROTECTIVE BACKING. LIFT ONE EDGE OF THE PROTECTIVE BACKING ENOUGH SO YOU CAN PEEL IT AWAY IF YOU HOLD THE PART IN POSITION. GENTLY POSITION THE ACCESSORY IN PLACE AND SLOWLY PEEL THE PROTECTIVE BACKING OFF WHILE ADHERING THE ACCESSORY IN PLACE. APPLY SLOW, EVEN PRESSURE WITH A CLEAN DRY RAG AND PUSH FIRMLY IN PLACE, RUBBING FROM THE CENTER OUT TOWARD THE EDGES.
4. **MAINTENANCE** - THE ADHESIVE SHOULD BE ALLOWED TO SET FOR **72** HOURS BEFORE EXPOSURE TO RAIN OR WASHING. AFTER THE ADHESIVE SETS YOU CAN APPLY CHROME POLISH OR WAX TO THE ACCESSORY. PROPER PROTECTION FROM DAILY MOISTURE, SUCH AS DEW OR RAIN, WILL INCREASE THE LIFE OF ALL CHROME ACCESSORIES.

FAILURE TO INSTALL AN ACCESSORY AS PER THE ABOVE INSTRUCTIONS MAY VOID ANY IMPLIED OR WRITTEN WARRANTIES.