



0

0 0

L.E.D. CURVED PLATE FRAME with 3 ACCENT STRIPS

PARTS INCLUDED

2

3

3

1

1

1

- Curved License Frame with 3 L.E.D. Accent Strips Assembly
 - Hardware Kit Containing 6
 - 4" Black Nylon Cable Ties
 - **Dielectric Grease Pack** 1 1
 - 1" X 8" Tape with Adhesive
 - 1/2" Bumper Pads
 - 2 Cord Keepers 2
 - Rubber Grommets
 - 6 Female T-Taps
 - 6 Male Spades 4
 - 1/4"-20 X 9/16" Flat Socket Head Cap Screws
 - 1/4"-20 X 1/2" Hex head Cap Screws
 - 1/4"-20 X 7/8" Hex Head Cap Screws
 - 3 1/4"-20 Nylock Nuts
- 1/4" Flat Washers 7
- Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR **PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING** THE USE AND CARE OF THIS PRODUCT.

- WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY
- ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.
- **CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

TOOLS SUGGESTED

Set of Hex Wrenches, Set of Combination Wrenches or Socket Set and Ratchet, Wire Crimping Tool, Test Light

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

- STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.
 - **NOTE** Due to the varying sizes of license plates, modification of the plate may be necessary to fit.

CUSTOMER SERVICE 877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

 Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).

> •The product must be properly installed, maintained and operated under normal conditions.

·Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

•Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.

•Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.

•Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) vear. This includes, but is not limited to; control modules, wiring, chrome & other components.

Küryakyn makes no warranty of any kind in regard to other manufacturer1s products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.



kuryakyn.com

3152-21MC-0511 -cont.- **CAUTION!** Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.



PIC 1

STEP 2 Remove your license plate; set it aside, it will be re-used.

STEP 3 Determine the mounting location and orientation of the new license plate mount. Use any combination of the slots shown in PIC 1 and PIC 2 to mount the slotted back plate to the motorcycle using the three 1/4"-20 X 5/8" hex head cap screws, flat washers and nylock nuts. FIG 1 NOTE: Determine that you will have clearance, by test fitting the Chrome Plate Frame on the slotted back plate, in the desired location. The slotted back plate has a built-in angle, and you may have to adjust it up or down on the slots, or turn it 180 degrees for proper clearance. Tighten securely.

- STEP 4 If the license plate mount on the bike is too wide for the slotted back plate, install the included extended mount, using two 1/4"-20 X 7/8" hex head cap screws, flat washers and nylock nuts on the bike, then mount the slotted back plate to it using the three 1/4"-20 X 1/2" hex head cap screws and flat washers. PIC 3 NOTE: Determine that you will have clearance, by test fitting the Chrome Plate Frame on the slotted back plate, in the desired location. The slotted back plate has a built-in angle, and you may have to adjust it up or down on the slots, or turn it 180 degrees for proper clearance. Tighten all hardware securely.
 - **NOTE** Use the included adhesive pad for padding on custom applications.
- **STEP 5** Decide if you would like the LED accent on the top or the bottom of the license plate. Hold your license plate on the backing plate and place the Curved Frame over it; secure the frame with the four 1/4"-20 x 9/16" flat socket head cap screws.
- **STEP 6** Ensure proper clearance before riding the motorcycle.
- ATTENTION! A factory service manual may be helpful in performing this installation. Do not attempt to perform this installation if you are not confident in your ability to complete all of the steps in the procedure; consult a trained technician.
- **STEP 7** Locate the red, black, and white wires from the Accent Strips and the Red and Black wire from the plate light. The Red wires will be your Running lights, the Black wires are the Ground, and the White wire is the Brake light power.



EXTENDED

MOUNT





-cont.-

L.E.D. PLATE FRAME

INSTALLATION

PAGE

STEP 8 Locate the wire harness that goes to the tail light on the bike. Using a test light, determine the running light and brake light power wires and a ground wire. Mark each of these for reference.

- Install a female T-Tap to each of these wires. PIC 4
- **STEP 9** Route the wire harness from the plate light and the harness from the Accent strips to the location that you are going to tap into the bike's wire harness.
- **STEP 10** Take the Red wire from the license plate light and the Red wire from the Accent Strips, remove about 1/2" of the insulation from each, twist the exposed wires together and crimp one of the supplied Male Spades to them. PIC 5 Then plug this pair of wires into the female T-Tap on the running light power wire from Step 9. FIG 2, PIC 6
- FIG 2 Stock Harness Ground License Plate Light BLACK WIRES FROM PLATE LIGHT AND ACCENT STRIPS RED WIRES FROM PLATE LIGHT AND ACCENT STRIPS WHITE WIRE FROM ACCENT STRIPS of
- **STEP 11** Take the White wire from the Accent Strip, remove about 1/2" of the insulation from it, and crimp a Male Spade to it. PIC 5 Plug it into the female T-Tap on the Brake Power from Step 9. FIG 2, PIC 6
- **STEP 12** Take the Black wire from the plate light and the Black wire from the Accent Strips, remove about 1/2" of the insulation from each, twist the exposed wires together and crimp a male Spade to them. PIC 5 Plug this pair into the female T-Tap on the ground wire from Step 9. Fig 2, PIC 6
- **STEP 10** Turn the key on and check for proper functions on the tail light and the new LED Plate Light and LED Accent Strips. Secure all the wires up and out of harms way.
- WARNING! ENSURE PROPER TAILLIGHT AND BRAKE LIGHT OPERATION BEFORE RIDING THE MOTORCYCLE. VISIBILITY IS A MAJOR CONCERN FOR MOTORCYCLISTS. TAILLIGHT OR BRAKE LIGHT MALFUNCTION COULD RESULT IN DEATH OR SERIOUS INJURY.
- ATTENTION! Secure all wiring away from any moving parts, pinch points or extreme heat. Küryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

Ride On!

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.









L.E.D. PLATE FRAME

INSTALLATION

|*Küryakyn*°